



**MOUNTING PAD PREPARATION**  
**BFP1-S, BFP2-S**

MODEL NUMBER	ENCLOSURE DESCRIPTION	INSIDE DIMENSIONS			OUTSIDE DIMENSIONS			CONCRETE PAD DIMENSIONS			SHIPPING WEIGHT
BFP1-S	1" W/STRAINER	30"L	10"W	22"H	33"L	13"W	24"H	45"L	25"W	6"T	45#
BFP2-S	2" W/STRAINER	43"L	14"W	28"H	46"L	17"W	30"H	58"L	29"W	6"T	65#

1. Using the chart above, provide a concrete pad 6" thick centered around the BFP device.
  - A. Provide expansion material around the BFP risers.
  - B. Place electrical conduit in pad if heat is required, before concrete is poured.
  - C. Finish concrete level and smooth. Allow concrete to cure before setting enclosure.
  - D. Electrical power source must comply with all local and national codes.