



OPERATIONS & MAINTENANCE SCHEDULE

AquaSHIELD enclosures are designed for ease of use and require minimum maintenance.

Before each cold season, inspections should include the following:

Heaters:

- Insure that power is supplied to the heater and the GFCI is in working order.
- Inspect the position of the thermostat. (Set to the factory arrow marker or 40° F)
- Insure proper operation of the heater. (An ice cube on the sensor bulb is recommended)

Enclosure:

- A visual inspection for physical damage and leaks is recommended upon every visit.
- Insure proper operation of all locks, latches, and handles upon every visit.
- Notify AquaSHIELD of any missing or damaged insulation panels.

Accessories:

- Insure proper operation of any and all accessories including:
 - Strobe lights
 - Wet location lights
 - Temperature alarms
 - Exhaust fans & louvers

